

INFORMATION PACK

Castle dimensions & space requirements

Please confirm your setup area against the measurements below before your booking date. If anything is unclear, send us a photo of the space and we will check it for you.

CASTLE BASE

8.0 × 5.0 m

TOTAL SPACE NEEDED

11.0 × 8.0 m


PEAK HEIGHT

3.234 m

INDOOR CLEARANCE

4.0 m min.

TECHNICAL DRAWING — ALL MEASUREMENTS IN MM



Space & surface

- **1.5 m clear on all sides** of the castle base, free of furniture, planters, washing lines and overhanging branches.
- Suitable surfaces: **level grass, artificial turf, or an indoor hard floor.**
- We cannot set up on **slopes, uneven ground or gravel.**
- Indoor venues need a **height clearance of at least 4 m.**

Access

- Gate or passage access of **at least 1.5 m wide** from the vehicle to the setup area.
- **No stairs or steps** along the access route.

Power

- **Two dedicated plug points** are required, so that each blower runs on its own point.
- The blowers run continuously for the duration of the hire.
- We provide **two 10 m extension cords.**

Setup & pack-down

- Setup requires **30 minutes access** before your start time, excluding balloon detail.
- Balloon detail on the jumping castle can add an **additional 45 minutes or more** after setup.
- Take-down requires **45 minutes** to fold and package.

